Quick Installation Guide Zmodo Fox IP Camera

Package Includes

- (1) Camera Power Adapter (1) Mounting Kit
- (1) Network Cable (1) Quick Start Guide

Download (Website: http://www.zmodo.com/support-software/) **List Includes:**

Zsight-iOS(Software)

Zsight-Android (Software)

Zviewer-Windows (Software)

Zviewer-iOS(Software)


Zviewer-Android(Software)

Zmdplayer(Software)

IPCSearch(Software)

IP Camera User Manual (PDF File)

GETTING STARTED



- 1.Please make sure that router's **DHCP** and **UPNP** are enabled before
- 2.The camera must be connected to your router using a network cable before it is set up to use Wi-Fi. Your mobile device must be connected to the same Wi-Fi network as the camera.

CONNECTING TO YOUR CAMERA ON IOS AND ANDROID

System Requirements: iPhone: iPhone v4.3 up and a valid iTunes account. Android: Android v2.3 up.

1 Download and install Zmodo Zsight software from the App store(iPhone) or Google play (Android) or download from website:

www.zmodo.com/support-software/





Tap the icon from the home screen to open Zmodo Zsight, and click [Add], this will take you to the "Add Device" section.



3 Tap the image of QR code, then scan the QR code area on the IP camera





The device will automatically enter the Wi-Fi interface.




Select your Wi-Fi network. Enter the Wi-Fi password, and select [Save].



6 Click [Next], enter the default password "111111", and click [Save].



7 Disconnect the network cable and place the camera anywhere within the Wi-Fi signal range.



8 Select the device from the [List] on your mobile device, and you will be able to see the video stream.




★ Install the ZViewer windows software from www.zmodo.com/support-software/. There are two ways to connect your camera on PC.

First Method: Remote connection by adding IP Camera's ID


1 Launch ZViewer on your PC, enter "User Name" (Default: admin) and 'Password" (Default: 111111), then click [Login].



4 Click [Device by ID], enter ID number, and click [Next].




2 Find "Setting", and click [Device Management].




* Note: IP Camera and Internet must be connected.


5 Enter "Login"(Default: admin) and "Password" (Default: 111111), then click [Finish].



3 Right click in the blank area on the right, then select [Add].



6 Go back to the Live interface, right click the device from the list, and select "open video", the video stream will display in the first available window.




Second Method: Search your LAN ★ *Note*: IP Camera and PC must be in the same LAN.


1 Launch ZViewer on your PC, enter "User Name" (Default: admin) and "Password" (Default: 111111), then click [Login].



2 Find "Discovery", and click [Search] on left bottom to search device.



3 Click [Add all] to add your device, you will be prompted after successfully adding it.



4 Go back to the Live interface, right click a device name from the Device List, then click [Open Video].



5 The video can now be seen within your local network.



Follow the steps below to troubleshoot issues.

1 Unable to access IP Camera by 3G or Internet

Ensure router's hotspot is turned on. Ensure [UPNP] is enabled on the router.

Unable to access Internet after your device was successfully set-up.

Unplug the power of camera, wait 10 seconds then power the device again. The Wi-Fi function will restart.

Wireless Security System

If you ever have any problems setting up or using this product, call the TOLL-FREE number below for additional assistance.

FREE 866-551-6881 one Service Hours: Mon-Fri 8:00am-8:00pm CST